

Subaru 2.5Ltr Forester, Liberty & Outback Replacement Flywheel Ring Gear

Ref: TN004

Issue date: 14 Dec 2004

Issue number: 2

Instructions to replace Dual Mass Flywheel with Solid Type Flywheel.

The ring gear must be removed and refitted to solid flywheel.

1. Remove retaining clip **(A)**. This enables the two sections of the dual mass flywheel to be separated.
2. Drill out 16 rivets **(B)**.
3. Clamp flywheel in a vice and using a chisel, tap firmly at back of ring gear in 3 or 4 places enabling its removal.
4. Heat ring gear and fit on to new flywheel.

