

# GM Holden 3.6L V6 – Revised CSC Spacer Fitment

Ref: TN104

Issue date: Feb 2018

Issue number: 1

## GMK-7744

### (Replacement Kit for EXEDY Single Mass Flywheel)

When installing GMK-7744 onto an EXEDY Single Mass Flywheel, it is important to remove and replace the old CSC Spacer with the 7mm Spacer supplied in this kit (Fig 1). Failure to do so may result in premature clutch failure.

Please refer to the below image for identification and location of relative spacers.

